


RS700 Rack Setting Widths

The RS700 weight compensation system requires sailors to adjust the width of their wing bars (racks) in accordance with the Rack Position Chart in Appendix 7 to the Class Rules¹. As the rack setting holes are drilled by the licenced builder, there should be no requirement to check that these hole settings (1-8) correspond to the correct rack widths, however for reference they are as follows:



Rack Hole Setting	Rack Width
Hole 1	1.98m
Hole 2	2.09m
Hole 3	2.19m
Hole 4	2.3m
Hole 5	2.4m
Hole 6	2.505m
Hole 7	2.61m
Hole 8	2.71m

¹ The 2019/2020 UK and Czech Republic events will use separately published Trial Rack Settings.